

Sublimation Ceramic Storage Jar with Bamboo Lid

SUBLIMATION

Printing	When using SubliJet refer to the Sawgrass Print Manager Manual. If using Epson or another brand of ink, use the instruction manual provided from the vendor you purchased your ink from. All images should be MIRRORED unless specified below.
Important	When the image is printed, it may look dull on the paper—this is normal. Trim the image to make it easier to position on your item. Secure your image to the object with heat tape to keep it from slipping or shifting.
	When pressing is done, Open the press slowly and gently remove the object and remove the paper (be careful not to let the paper shift across the surface of the object, or you may create a "ghost" image).
Oven Setup	Before placing the jars in oven, make sure the convection oven reached the idle temperature. Remove bamboo lid prior to placing in oven.
	Recommended shrink wrap W 9.05" x H 6.5" (P-SUB-SF-230165).
Oven Curing	Oven Temperature: 360°F Press Time: 15-18 minutes
J	hot peel
	1. Remove ceramic jar's bamboo lid prior to placing in oven.
	2. Set the convection oven at 360°F for 15-18 minutes. Please refer to table below for exact time as time may vary based on jar size.
	3. Ensure convection oven has reached the set temperature
	4. Tape imaged sublimation paper onto your ceramic jar. Image facing the glass.
	5. Place shrink wrap (W 9.05" x H 6.5") around ceramic jar. Use dryer/heatgun to heat the shrink wrap which will tighten the shrink wrap around the ceramic jar.
	 Place ceramic jar in convection oven. Ensure that it is not touching other object in the oven.
	 Once the timer counts to zero, open convection oven, and take glass out. Use gloves or heat resistant cloth to handle the hot glass.
	 Once the timer counts to zero, open convection oven, and take glass out. Use gloves or heat resistant cloth to handle the hot glass. 8. Rip off the shrink wrap, then peel sublimation paper off.
	Use gloves or heat resistant cloth to handle the hot glass.
	Use gloves or heat resistant cloth to handle the hot glass. 8. Rip off the shrink wrap, then peel sublimation paper off.
	Use gloves or heat resistant cloth to handle the hot glass.8. Rip off the shrink wrap, then peel sublimation paper off.9. Leave on table to cool. Do not dunk in water.
g Time &	 Use gloves or heat resistant cloth to handle the hot glass. 8. Rip off the shrink wrap, then peel sublimation paper off. 9. Leave on table to cool. Do not dunk in water. Caution: Ceramic jar is extremely hot when in the oven, do not handle with bare hands Note: Temperature and time settings are only a guide/starting point, some convection ovens may require some fine tweaking of the temperature and time. Only use a convection oven, do
g Time & erature	 Use gloves or heat resistant cloth to handle the hot glass. 8. Rip off the shrink wrap, then peel sublimation paper off. 9. Leave on table to cool. Do not dunk in water. Caution: Ceramic jar is extremely hot when in the oven, do not handle with bare hands Note: Temperature and time settings are only a guide/starting point, some convection ovens may require some fine tweaking of the temperature and time. Only use a convection oven, do not use a conventional oven.

Tel: 1-800-565-5686 | Fax: 1-800-565-5622 | www.jotoimagingsupplies.com Blaine WA, Las Vegas NV, Antioch TN, Coquitlam BC, Brampton ON