

PAROPY INKJET WATER SLIDE (FOR DARKS)

APPLICATION INSTRUCTIONS

NOTES

Recommended Materials

Black or Dark Colored
Candles
Glass
Metal
Wood
Soap
Decorative plates,
Mugs, etc.

Accessories Required

Computer, Inkjet
Printer, Acrylic Varnish
Spray, Tissues or
Towel, Water, Squeegee
rubber, Scissors, hair
dryer(optional)

Printable side

The printable side is
the white glossy coated
side.

Storage

Paropy Inkjet Water
Slide Paper has an
indefinite shelf life
when stored at room
temperature. Keep
away from direct heat,
sunlight, and humidity.

Tips

If it is cold outside, you
should use warm water.

Instead of waiting for
3-4 hours, you can use
hair dryer to dry the
paper.

STEP BY STEP

Paropy Inkjet Water Slide Paper will allow you to image heat sensitive substrates or substrates which are decorative and will not be washed.

This paper will work in most Inkjet printers. It is recommended that you do a test before commercial application.

Step 1

Edit the size and shape of your image.
Do NOT Mirror your image.

Step 2

Print image on the glossy side of the
water slide paper.
*Set the printer settings to 175g or a
thicker/heavier paper setting. Use the
bypass tray.

Step 3

Spray a thin coat of acrylic varnish spray
over the printed area. Make sure you
spray about a meter away from the
paper. The ink must be sufficiently
covered with varnish to be protected.

Step 4

Before continuing to the next step,
make sure that the varnish is dried
completely. Leave it drying for about an
hour or use a hair-dryer for a quick dry.

If the paper is dry and smooth to touch,
it is ready.

Step 5

Use a pair of scissors or craft knife to
cut out your image. Cut as closely as
you can to the image. Try to not leave
any edges as it will show as white.

Step 6

Once the paper is cut, place the paper
in a bowl of water, and leave it for 30
seconds.

Step 7

Wet the surface of your substrate with
water. It will allow you to move the
image easily to the right spot.

Step 8

If you have soaked the paper long
enough, the backing paper will come
off easily (do not remove the backing
paper just yet)

Take the paper out, press against the
substrate face up, then remove the
backing paper.

Step 9

Gently tug the backing to let the film
sit on the surface.

Step 10

Squeegee out once the paper is in
the right spot. Take extra care when
handling the thin paper.

Let dry for 3-4 hours.